



TECHNICAL INFORMATION

09. July 2021

TI1121

Machine type/s:

SiVend-machines

Topping-up cards with pre-determined credit

Cashless payment is increasing in popularity. Company caterers are using cashless systems with a pre-determined credit limit. Our machines with a 2-/4- line display can also be used to top-up cards. Please see below how your machine must be configured so that a banknote can be used to top-up a card.

Topping-up

In this scenario the banknote is only credited against the card. A product sale can not be initiated by the banknote.

Hardware configuration:

Banknote reader	Yes
Cashless reader	Yes

Software configuration

1. [Credit] on
2. Disable by using [01].

Explanation

Disabled notes are used by the machine software for topping-up. Banknotes have the following status:

- [00](Banknote is always accepted)
- [10](Banknote is checked with a higher level of accuracy)
- [01] (Banknote is disabled)



TECHNICAL INFORMATION

Product selection

When a sale is made using cashless systems we recommend checking the [Preset Time]. By doing so the time between product selection and payment can be determined.

Refund

If only cashless payments are accepted and the machine displays [CORRECT CHANGE], under [CORRECT CHANGE] the menu should be set to [never].

Sielaff GmbH & Co. KG Automatenbau Herrieden