

TECHNICAL INFORMATION

16. January 2019

TI0119

Machine type/s:

Robimat 75 / 99

New lift software for Robimat 75 / 99

Additional mounting parts on the basket has changed the height of the basket. The test run which can be selected has therefore been modified in the lift control board software. As the basket travels to the top of the machine in the test run, the newly fitted bracket would cause jamming. In order to avoid this the upper travel position been adjusted for the test run.

Machine	Software	Ex works
Robimat 75 / 99	roblx914.hex	11/2018

The latest corresponding software can be found on our Homepage in the Download-Center

(<http://www.sielaff.de/download-center/>).

Sielaff GmbH & Co. KG

